



BETASEAL™ 3000HMNC

- Chemical cure
- One hour safe drive away at temperatures as low as 40°F (4.4°C)

Preserve the quality of precision automobiles

- Retains torsional stiffness to quiet and stabilize the vehicle's ride
- Preserves radio, cellular phone and global positioning system reception in antenna encapsulated auto glass



BETASEAL™ 1500HV

- Moisture cure
- OEM approved



NAGS Number	Year	Make	Model	HM	NC	NAGS Number	Year	Make	Model	HM	NC	NAGS Number	Year	Make	Model	HM	NC
FW 00614	1995	BMW	5 Series	X		FW 02169	1999-2000	Mercedes	CLK	X	X	FR 20248	1996-1998	Porsche	911	X	X
FW 00679	1995-1997	BMW	8 Series		X	FW 02170	1999-2000	Mercedes	CLK	X	X	FR 20249	1996-1998	Porsche	911	X	X
FW 00728	1996	Volkswagen	Golf	X		FW 02175	2000	Mercedes	C-Class	X	X	FB 20254	1998-2000	Volvo	S70	X	
FW 00740	1995	Mercedes	E-Class	X	X	FW 02177	2000	Mercedes	A-Class	X		FQ 20255	1998	Volvo	V90	X	
FW 00743	1995	Mercedes	E320	X	X	FB 03243	1998	Volvo	V90	X		FB 20266	1997-1999	Volkswagen	Jetta	X	
FW 00744	1998-1999	Mercedes	C-Class	X	X	FB 03439	1995	Mercedes	E320	X	X	FB 20273	1998-1999	Mercedes	C-Class	X	X
FW 00750	1995-1999	Mercedes	C-Class	X	X	FB 04075	1995	Mercedes	E320	X	X	FB 20353	1998-2000	Volkswagen	Passat	X	
FW 00774	1995-1998	Audi	Cabriolet	X	X	FB 04076	1995	Mercedes	E-Class	X	X	FB 20377	1997-1999	Volkswagen	Golf	X	
FW 00784	1995-1997	Audi	A-6	X	X	FB 04110	1995-1998	Porsche	911	X	X	FQ 20387-88	1998-2000	Volkswagen	New Beetle	X	
FW 00789	1995-2000	BMW	7 Series		X	FB 04256	1995-1998	Porsche	911	X	X	FB 20389	1998-2000	Volkswagen	New Beetle	X	
FW 00807	1995	Jaguar	XJ Series	X		FB 04277	1996-1997	Volkswagen	Passat	X		FB 20438	1999-2000	Saab	9-5	X	
FW 00808	1995	Jaguar	XJ Series	X		FQ 04278-79	1996-1997	Volkswagen	Passat	X		FB 20466	1998-1999	Mercedes	CLK	X	X
FW 00811	1996-1997	Volkswagen	Passat	X		FB 04417	1998	Volvo	S90	X		FB 20480	1999-2000	Porsche	911	X	X
FW 00815	1995-1996	Jaguar	XJ Series	X		FQ 04436-37	1995-1997	BMW	8 Series		X	FQ 20489-90	1998-2000	Audi	A-6	X	
FW 00816	1995-1996	Jaguar	XJ Series	X		FB 04438-39	1995-1997	BMW	8 Series		X	FQ 20491-92	1998-2000	Audi	A-6	X	
FW 00818	1996-2000	Mercedes	E-Class	X	X	FQ 04440	1995-1997	BMW	8 Series		X	FB 20493	1998-2000	Audi	A-6	X	
FW 00823	1996-2000	Audi	A-4	X		FQ 04587-88	1995-1997	Audi	A-6	X	X	FB 20494	1998-2000	Audi	A-6	X	
FW 02004	1996-2000	Volkswagen	Cabrio	X		FB 04589	1995-1997	Audi	A-6	X	X	FB 20617	1999-2000	Volkswagen	Jetta	X	
FW 02005	1998-1999	Volvo	S90/V90	X		FB 04630	1997-2000	Volkswagen	Eurovan	X		FB 20628	1999-2000	Volkswagen	Golf	X	
FW 02006	1996-1999	Volkswagen	Jetta	X		FB 04711	1995-1999	BMW	5 Series		X	FQ 20645-46	1995-1997	Audi	A-6	X	X
FW 02007	1995-2000	BMW	5 Series		X	FB 04720	1995-1999	BMW	5 Series		X	FB 20653	1998-2000	Volkswagen	Passat	X	
FW 02020	1996-1997	Jaguar	XJ Series	X		FB 04727	1995-1997	Audi	A-6	X	X	FQ 20667-68	1998-2000	Jaguar	XJ8	X	
FW 02021	1996-1997	Jaguar	XJ Series	X		FQ 04730-31	1996-1999	Volkswagen	Golf	X		FQ 20669-70	1998-2000	Jaguar	XJR	X	
FW 02026	1997-2000	Jaguar	XK8	X		FB 04732	1996	Volkswagen	Golf	X		FB 20671	1998-2000	Jaguar	XJ8-XJR	X	
FW 02027	1997-2000	Jaguar	XK8	X		FB 04733	1996	Volkswagen	Golf	X		FB 20672	1998-2000	Jaguar	XJ8-XJR	X	
FW 02028	1997-2000	Audi	A-8	X	X	FB 04740	1996	Volkswagen	Jetta	X		FB 20673	1998-2000	Jaguar	XJ8	X	
FW 02029	1997-2000	Porsche	Boxster	X	X	FB 04741	1996-1997	Volkswagen	Passat	X		FB 20674	1998-2000	Jaguar	XJ8	X	
FW 02032	1996-1998	Porsche	911	X	X	FB 04839	1998-1999	Mercedes	C-Class	X	X	FQ 20679-80	1998-2000	Audi	A-6	X	
FW 02041	1998-2000	Mercedes	SLK	X	X	FB 04844	1995-1997	Audi	A-6	X	X	FQ 20681-82	1998-2000	Audi	A-6	X	
FW 02044	1997-2000	Audi	A-8	X	X	FB 04885	1995-1999	Mercedes	C-Class	X	X	FB 20683	1998-2000	Audi	A-6	X	
FW 02045	1995-1999	Mercedes	C-Class	X	X	FB 04927	1998	Volvo	S90	X		FB 20684	1998-2000	Audi	A-6	X	
FW 02046	1998-1999	Mercedes	C-Class	X	X	FB 05280	1995-1997	Audi	A-6	X	X	FB 20773	2000	Mercedes	S-Class	X	X
FW 02052	1998-2000	Volvo	S70/V70	X		FB 05329	1998-2000	Volvo	V70	X		FV 20784-85	2000	Audi	TT	X	
FW 02053	1997-2000	Volkswagen	Eurovan	X		FQ 05330	1998	Volvo	V90	X		FQ 20788-89	2000	Audi	TT	X	
FW 02056	1998-2000	Mercedes	E-Class	X	X	FB 05422	1995-2000	BMW	7 Series		X	FB 20790	2000	Audi	TT	X	
FW 02067	1998-2000	Volkswagen	Passat	X		FV 05566-67	1996-1999	Mercedes	E-Class	X	X	FB 20817	1998-2000	Volkswagen	New Beetle	X	
FW 02072	1998-2000	Volkswagen	New Beetle	X		FB 05568	1996-1999	Mercedes	E-Class	X	X	FB 20886	1998-2000	Volvo	V70	X	
FW 02078	1998-2000	Mercedes	CLK	X	X	FB 05588	1998-2000	Mercedes	E320	X	X	FB 20935	2001	Mercedes	C-Class	X	X
FW 02079	1998-2000	Mercedes	CLK	X	X	FQ 05593-94	1996-2000	Audi	A-4	X		FQ 20945-46	1999-2000	Saab	9-5	X	
FW 02082	1998-2000	Jaguar	XJ8-XJR	X		FB 05595	1996-2000	Audi	A-4	X		FB 20947	1999-2000	Saab	9-5	X	
FW 02083	1998-2000	Jaguar	XJ8-XJR	X		FV 20014-15	1997-2000	BMW	5 Series		X	FQ 20950-51	1998-2000	Audi	A-4/S-4	X	
FW 02088	1999-2000	Saab	9-5	X		FB 20016	1995-2000	BMW	5 Series		X	FQ 20952-53	1998-2000	Audi	A-4/S-4	X	
FW 02096	1999-2000	Porsche	911	X	X	FB 20096	1995-1997	Jaguar	XJ Series	X		FB 20954	1998-2000	Audi	A-4/S-4	X	
FW 02097	1998-2000	Audi	A-6	X		FB 20097	1995-1997	Jaguar	XJ Series	X		FB 20955	1998-2000	Audi	A-4/S-4	X	
FW 02098	1998-2000	Audi	A-6	X		FB 20150	1997-2000	Jaguar	XK8	X		FB 20992	2001	Mercedes	C-Class	X	X
FB 02115	1999-2000	Volkswagen	Golf/Jetta	X		FQ 20155-56	1997-2000	Audi	A-8	X	X	FV 21006-07	2000	Mercedes	A-Class	X	
FW 02117	1999-2000	Volkswagen	Golf/Jetta	X		FB 20157	1997-2000	Audi	A-8	X	X	FQ 21008-09	2000	Mercedes	A-Class	X	
FW 02122	1998-2000	Audi	A-6	X		FQ 20227-28	1997-2000	Audi	A-8	X	X	FB 21010	2000	Mercedes	A-Class	X	
FW 02123	1998-2000	Audi	A-6	X		FB 20229	1997-2000	Audi	A-8	X	X						
FW 02124	1998-2000	Volkswagen	Passat	X		FB 20234	1996-1999	Mercedes	E-Class	X	X						
FW 02141	2000	Mercedes	S-Class	X	X	FB 20239	1998-2000	Mercedes	SLK	X	X						
FW 02142	2000	Audi	TT	X		FB 20246	1996-1998	Porsche	911	X	X						
FW 02165	2001	Mercedes	C-Class	X	X	FB 20247	1996-1998	Porsche	911	X	X						

High Modulus, Nonconductive Auto Glass Urethane Adhesives Application chart by Make and Model

Essex ARG
Dow Automotive Aftermarket
555 Gaddis Boulevard
Dayton, Ohio 45403
1-800-453-ESSX (3779)
www.essexarg.com



BETASEAL™ 3000HMNC

- Chemical cure
- One hour safe drive away at temperatures as low as 40°F (4.4°C)

Preserve the quality of precision automobiles

- Retains torsional stiffness to quiet and stabilize the vehicle's ride
- Preserves radio, cellular phone and global positioning system reception in antenna encapsulated auto glass



BETASEAL™ 1500HV

- Moisture cure
- OEM approved



NAGS Number	Year	Make	Model	HM	NC	NAGS Number	Year	Make	Model	HM	NC	NAGS Number	Year	Make	Model	HM	NC
FW 00823	1996-2000	Audi	A-4	X		FB 20096	1995-1997	Jaguar	XJ Series	X		FB 20246	1996-1998	Porsche	911	X	X
FQ 05593-94	1996-2000	Audi	A-4	X		FB 20097	1995-1997	Jaguar	XJ Series	X		FB 20247	1996-1998	Porsche	911	X	X
FB 05595	1996-2000	Audi	A-4	X		FW 02020	1996-1997	Jaguar	XJ Series	X		FR 20248	1996-1998	Porsche	911	X	X
FQ 20950-51	1998-2000	Audi	A-4/S-4	X		FW 02021	1996-1997	Jaguar	XJ Series	X		FR 20249	1996-1998	Porsche	911	X	X
FQ 20952-53	1998-2000	Audi	A-4/S-4	X		FQ 20667-68	1998-2000	Jaguar	XJ8	X		FW 02096	1999-2000	Porsche	911	X	X
FB 20954	1998-2000	Audi	A-4/S-4	X		FB 20673	1998-2000	Jaguar	XJ8	X		FB 20480	1999-2000	Porsche	911	X	X
FB 20955	1998-2000	Audi	A-4/S-4	X		FB 20674	1998-2000	Jaguar	XJ8	X		FW 02029	1997-2000	Porsche	Boxster	X	X
FB 04727	1995-1997	Audi	A-6	X	X	FW 02082	1998-2000	Jaguar	XJ8-XJR	X		FW 02088	1999-2000	Saab	9-5	X	
FB 04844	1995-1997	Audi	A-6	X	X	FW 02083	1998-2000	Jaguar	XJ8-XJR	X		FB 20438	1999-2000	Saab	9-5	X	
FW 00784	1995-1997	Audi	A-6	X	X	FB 20671	1998-2000	Jaguar	XJ8-XJR	X		FQ 20945-46	1999-2000	Saab	9-5	X	
FQ 04587-88	1995-1997	Audi	A-6	X	X	FB 20672	1998-2000	Jaguar	XJ8-XJR	X		FB 20947	1999-2000	Saab	9-5	X	
FB 04589	1995-1997	Audi	A-6	X	X	FQ 20669-70	1998-2000	Jaguar	XJR	X		FW 02004	1996-2000	Volkswagen	Cabrio	X	
FB 05280	1995-1997	Audi	A-6	X	X	FW 02026	1997-2000	Jaguar	XK8	X		FW 02053	1999-2000	Volkswagen	Eurovan	X	
FQ 20645-46	1995-1997	Audi	A-6	X	X	FW 02027	1997-2000	Jaguar	XK8	X		FB 04630	1997-2000	Volkswagen	Eurovan	X	
FW 02097	1998-2000	Audi	A-6	X		FB 20150	1997-2000	Jaguar	XK8	X		FW 00728	1996	Volkswagen	Golf	X	
FW 02098	1998-2000	Audi	A-6	X		FW 02177	2000	Mercedes	A-Class	X		FB 04732	1996	Volkswagen	Golf	X	
FW 02122	1998-2000	Audi	A-6	X		FV 21006-07	2000	Mercedes	A-Class	X		FB 04733	1996	Volkswagen	Golf	X	
FW 02123	1998-2000	Audi	A-6	X		FQ 21008-09	2000	Mercedes	A-Class	X		FQ 04730-31	1996-1999	Volkswagen	Golf	X	
FQ 20489-90	1998-2000	Audi	A-6	X		FB 21010	2000	Mercedes	A-Class	X		FB 20377	1997-1999	Volkswagen	Golf	X	
FQ 20491-92	1998-2000	Audi	A-6	X		FW 02165	2001	Mercedes	C-Class	X	X	FB 20628	1999-2000	Volkswagen	Golf	X	
FB 20493	1998-2000	Audi	A-6	X		FB 20935	2001	Mercedes	C-Class	X	X	FB 02115	1999-2000	Volkswagen	Golf/Jetta	X	
FB 20494	1998-2000	Audi	A-6	X		FW 00750	1995-1999	Mercedes	C-Class	X	X	FW 02117	1999-2000	Volkswagen	Golf/Jetta	X	
FQ 20679-80	1998-2000	Audi	A-6	X		FW 02045	1995-1999	Mercedes	C-Class	X	X	FB 04740	1996	Volkswagen	Jetta	X	
FQ 20681-82	1998-2000	Audi	A-6	X		FB 04885	1995-1999	Mercedes	C-Class	X	X	FW 02006	1996-1999	Volkswagen	Jetta	X	
FB 20683	1998-2000	Audi	A-6	X		FW 02046	1998-1999	Mercedes	C-Class	X	X	FB 20266	1997-1999	Volkswagen	Jetta	X	
FB 20684	1998-2000	Audi	A-6	X		FB 04839	1998-1999	Mercedes	C-Class	X	X	FB 20617	1999-2000	Volkswagen	Jetta	X	
FW 02028	1997-2000	Audi	A-8	X	X	FB 20273	1998-1999	Mercedes	C-Class	X	X	FW 02072	1998-2000	Volkswagen	New Beetle	X	
FQ 02044	1997-2000	Audi	A-8	X	X	FW 02175	2000	Mercedes	C-Class	X	X	FQ 20387-88	1998-2000	Volkswagen	New Beetle	X	
FW 20155-56	1997-2000	Audi	A-8	X	X	FB 20992	2001	Mercedes	C-Class	X	X	FB 20389	1998-2000	Volkswagen	New Beetle	X	
FB 20157	1997-2000	Audi	A-8	X	X	FW 00744	1998-1999	Mercedes	C-Class	X	X	FB 20817	1998-2000	Volkswagen	New Beetle	X	
FQ 20227-28	1997-2000	Audi	A-8	X	X	FW 02078	1998-2000	Mercedes	CLK	X	X	FW 00811	1996-1997	Volkswagen	Passat	X	
FB 20229	1997-2000	Audi	A-8	X	X	FW 02079	1998-2000	Mercedes	CLK	X	X	FB 04277	1996-1997	Volkswagen	Passat	X	
FW 00774	1995-1998	Audi	Cabriolet	X	X	FB 20466	1998-1999	Mercedes	CLK	X	X	FQ 04278-79	1996-1997	Volkswagen	Passat	X	
FW 02142	2000	Audi	TT	X		FW 02169	1999-2000	Mercedes	CLK	X	X	FB 04741	1996-1997	Volkswagen	Passat	X	
FV 20784-85	2000	Audi	TT	X		FW 02170	1999-2000	Mercedes	CLK	X	X	FW 02067	1998-2000	Volkswagen	Passat	X	
FQ 20788-89	2000	Audi	TT	X		FW 00743	1995	Mercedes	E320	X	X	FW 02124	1998-2000	Volkswagen	Passat	X	
FB 20790	2000	Audi	TT	X		FB 03439	1995	Mercedes	E320	X	X	FB 20353	1998-2000	Volkswagen	Passat	X	
FW 00614	1995	BMW	5 Series		X	FB 04075	1995	Mercedes	E320	X	X	FB 20653	1998-2000	Volkswagen	Passat	X	
FB 04711	1995-1999	BMW	5 Series	X		FB 05588	1998-2000	Mercedes	E320	X	X	FB 20254	1998-2000	Volvo	S70	X	
FB 04720	1995-1999	BMW	5 Series	X		FW 00740	1995	Mercedes	E-Class	X	X	FW 02052	1998-2000	Volvo	S70/V70	X	
FW 02007	1995-2000	BMW	5 Series	X		FB 04076	1995	Mercedes	E-Class	X	X	FB 04417	1998	Volvo	S90	X	
FB 20016	1995-2000	BMW	5 Series	X		FV 05566-67	1996-1999	Mercedes	E-Class	X	X	FB 04927	1998	Volvo	S90	X	
FV 20014-15	1997-2000	BMW	5 Series	X		FB 05568	1996-1999	Mercedes	E-Class	X	X	FW 02005	1998-1999	Volvo	S90/V90	X	
FW 00789	1995-2000	BMW	7 Series	X		FB 02034	1996-1999	Mercedes	E-Class	X	X	FB 05329	1998-2000	Volvo	V70	X	
FB 05422	1995-2000	BMW	7 Series	X		FW 00818	1996-2000	Mercedes	E-Class	X	X	FB 20886	1998-2000	Volvo	V70	X	
FW 00679	1995-1997	BMW	8 Series	X		FW 02056	1998-2000	Mercedes	E-Class	X	X	FB 03243	1998	Volvo	V90	X	
FQ 04436-37	1995-1997	BMW	8 Series	X		FW 02141	2000	Mercedes	S-Class	X	X	FQ 05330	1998	Volvo	V90	X	
FB 04438-39	1995-1997	BMW	8 Series	X		FB 20773	2000	Mercedes	S-Class	X	X	FQ 20255	1998	Volvo	V90	X	
FQ 04440	1995-1997	BMW	8 Series		X	FW 02041	1998-2000	Mercedes	SLK	X	X						
FW 00807	1995	Jaguar	XJ Series	X		FB 20239	1998-2000	Mercedes	SLK	X	X						
FW 00808	1995	Jaguar	XJ Series	X		FB 04110	1995-1998	Porsche	911	X	X						
FW 00815	1995-1996	Jaguar	XJ Series	X		FB 04256	1995-1998	Porsche	911	X	X						
FW 00816	1995-1996	Jaguar	XJ Series	X		FW 02032	1996-1998	Porsche	911	X	X						